

Preliminary design of the pressure relief system for the EDIPO 2 He vessel

R. Guarino*

X. Sarasola

E. Solodko

P. Bruzzone

K. Sedlak

Swiss
Plasma
Center

CHATS-AS 2021

ITER, France

22-24 Sep. 2021

Outline


- Introduction
 - He vessel
 - Staged pressure protection
- Safety pressure relief device
- Pressure relief & He recovery
 - Quench energy deposition
 - Two/three-volume model
- Conclusions



Introduction

Roberto Guar

- The European DIPOle (EDIPO) is a test facility for fusion and high-energy physics superconducting samples.
- It is located in Villigen, Switzerland.
- An unprotected quench in 2016 led to an irreversible damage of the magnet assembly.
- EDIPO 2 is the upgraded design¹ with a target field of 15 T (~1 m uniform field length).







Swiss
Plasma
Center

¹ Araujo et al., Progress on the update of EDIPO, a 15 T large aperture dipole, *IEEE Transactions on Applied Superconductivity* **31** (2021) 9500205.


Objectives

- Instead of supercritical He cooling of the old EDIPO facility, a He bath cooling (~4.2 K, 1 atm) is the preferred choice for EDIPO 2.
- A He vessel has been designed and is currently under manufacturing (delivery by Q4 2021).
- A preliminary design of the pressure relief system is necessary.
- Two scenarios considered:
 - safety pressure relief after an accidental scenario (worst-case event)
 - pressure relief and He recovery during normal operation



He vessel schematic


- The He inlet is regulated through a Joule-Thomson valve.
- A burst disc is chosen as safety pressure relief device.
- The total He volume and filling level can be chosen in a wide range.
- A He recovery pipe connects the He vessel to a recovery volume (e.g. balloon at 1 atm pressure).





Staged pressure protection

- It is considered a good engineering practice in the design of cryogenic pressure systems².
- We fix the operating pressure and the maximum allowable working pressure.



Swiss
Plasma
Center

² Grohmann & Süßer, Conceptual design of pressure relief systems for cryogenic applications, *Advances in Cryogenic Engineering* **1573** (2014) 1581.

Safety pressure relief device

- The burst disc has been sized according to EN 13648-3.
- Two credible accidental events are considered:
 - unprotected quench (I_{op} in the range 14-18 kA and power supply with $V_{PS} \approx 5$ V)

$$\dot{Q} = I_{op}V_{PS}$$

• loss of vacuum (specific heat power deposition of 0.6 W/cm² on the vessel external surface³ $A_{vessel} \approx 14.2 \text{ m}^2$)

$$\dot{Q} = Q'A_{vessel}$$

• For I_{op} < 17.1 kA, the loss of vacuum represents the worst case scenario.



³ Lehmann & Zahn, Safety aspects for LHe cryostats and LHe transport containers, *Proceedings of the 7th International Engineering Conference*, London, 4-7 Jul 1978.



Safety pressure relief device

- The He flow through the burst disc is in subcritical conditions.
- The minimum flow area (i.e. burst disc diameter) can be computed.
- A conservative design is pursued by adding a safety factor on the maximum mass flow rate.

	Unprotected quench	Loss of vacuum
Maximum heat power	90.0 kW	85.4 kW
Maximum mass flow rate	5.03 kg/s	4.77 kg/s
Safety factor on mass flow rate	1.25	1.25
Minimum burst disc diameter	55.0 mm	53.6 mm


The closest standard (commercial) burst disc size is DN65.





Pressure relief & He recovery


- In normal operation one must relieve the rising pressure, e.g. after a protected quench, and it is desirable to recover the outflowing He.
- Through a thermodynamic analysis of the system, it is possible to:
 - simulate the He pressure rise following a quench
 - simulate the time evolution of the pressure (and temperature) after opening the relieving valve
 - provide an engineering tool to support the sizing of the recovery pipe
- We have developed a two/three-volume model, based on a simplified description of the system.




Swiss
Plasma
Center

Overview of existing models

- Two-volume model developed at CERN⁴, for studying quench in magnet strings.
- Two volume model developed at CEA⁵, for simulating the He pressure rise following a quench.
- Both models deal with superfluid He and simulate short time spans; no recovery pipes are included.






⁵ Meuris, Experimental simulation of helium pressure rise during a quench of a superconducting coil cooled by a superfluid helium bath, Cryogenics 53 (2013) 17. Center



⁴ Chorowski et al., Towards a better understanding of the physics of the two-volume model of accelerator magnet quench thermohydraulics, Cryogenics 46 (2006) 581.

Two/three-volume model overview

- Main features:
 - small volume A directly heated by the heat source (i.e. quench energy)
 - isentropic volume B (in the short time frame considered)
 - volume C 'active' only after valve opening
 - 'virtual pistons' that separate the two or three volumes



- Novelty:
 - pressure drop along the recovery pipe
 - "recirculation" (i.e. internal) mass flow rate



Quench energy deposition

quench energy $E_{coil}(t) = \int_{0}^{t} R_{coil}(t)I(t)^{2}dt$

diffusion through conduction+convection

$$\frac{T(t) - T_{\infty}}{T(0) - T_{\infty}} \approx r(\xi, \beta)$$

ξ,β functions of material properties and heat transfer coefficient (natural convection)


'delayed' quench energy to include diffusion $E_{coil}(t) \rightarrow E'_{coil}(t)$

$$E_{coil}(t) \rightarrow E'_{coil}(t)$$

energy fraction transferred to the He bath

$$E_{He}(t) \approx E'_{coil}(t) - m_{coil} \int_{T_0}^{T(t)} c_{coil}(T) dT - m_{ins} \int_{T_0}^{T(t)} c_{ins}(T) dT$$


heat power
$$\dot{Q}(t) = \frac{\mathrm{d}E_{He}(t)}{\mathrm{d}t}$$



Center

EPFL

Two-volume model



effect of energy deposition


$$\dot{m}_{vap}(t) = \frac{\dot{Q}(t)}{L_{vap}}$$

$$m_{vap}(t) = \int_0^t \dot{m}_{vap}(t) dt$$


assumption $\dot{m}_{cold} \approx \dot{m}_{vap}$

volume change

$$\frac{\mathrm{d}V_A(t)}{\mathrm{d}t} = \frac{\dot{m}_{vap}(t)}{\rho_{vap}} + \frac{\dot{m}_{cold}(t)}{\rho(0)}$$
$$\frac{\mathrm{d}V_B(t)}{\rho(0)} = -\frac{\mathrm{d}V_A(t)}{\rho(0)}$$



Three-volume model



effect of energy deposition


$$\dot{m}_{vap}(t) = \frac{\dot{Q}(t)}{L_{vap}}$$

$$m_{vap}(t) = \int_0^t \dot{m}_{vap}(t) dt$$

assumption $\dot{m}_{cold} \approx \dot{m}_{vap}$

volume change $\mathrm{d}V_A(t) = \dot{m}_{van}(t) = \dot{m}_{cold}$

$$\frac{\mathrm{d}V_A(t)}{\mathrm{d}t} = \frac{\dot{m}_{vap}(t)}{\rho_{vap}} + \frac{\dot{m}_{cold}(t)}{\rho(0)}$$
$$\frac{\mathrm{d}V_B(t)}{\mathrm{d}t} = -\frac{\mathrm{d}V_A(t)}{\mathrm{d}t} + \frac{\dot{m}_{out}(t)}{\rho(t)}$$




Swiss
Plasma
Center

mass flow rate through the valve

$$\rho(t) \frac{p_b^2 - p(t)^2}{2p(t)} + \frac{\dot{m}_{out}^2}{A^2} \left[\ln \frac{p(t)}{p_b} + \frac{2L}{D} f(t) \right] = 0$$

Two/three-volume model results


 Time variation of pressure and temperature (average values in the volume B), before and after valve opening.



Two/three-volume model sensitivity analysis

Roberto Guarino


Varying diameter and length of the recovery pipe.






Two/three-volume model sensitivity analysis

Varying relieving pressure and He total volume.





Conclusions

- The EDIPO 2 He vessel has been designed and is under manufacturing.
- A preliminary design of the pressure relief system has been presented:
 - staged pressure protection concept with 1 atm operating pressure and
 3.0 bar maximum allowable pressure
 - DN65 burst disc as safety pressure relief device
- A novel two/three-volume model has been developed:
 - study of quench energy deposition into the He bath
 - He pressure rise and pressure relief through a recovery pipe
 - sensitivity analyses based on 4 parameters: recovery pipe diameter (D) and length (L), relieving pressure (p_0) and total He volume (V_0)
 - potential design tool to support engineering choices (e.g. recovery pipe sizing)

Swiss
Plasma
Center





This work has been carried out within the framework of the EUROfusion Consortium and has received funding from the Euratom research and training programme 2014-2018 and 2019-2020 under grant agreement No 633053. The views and opinions expressed herein do not necessarily reflect those of the European Commission.

Acknowledgments

- Paul Scherrer Institut (PSI) for technical support
- Dr. Carolin Zoller for discussions

... thank you for your attention! Plasma

Center